



**TF1100-EP**  
**Transit Time Ultrasonic Flow (Heat) Meter**  
**Portable**

Operation & Maintenance

Manual

REV 1/2023

# CONTENTS

<b>PART-1 INTRODUCTION .....</b>	<b>1</b>
1.1 GENERAL .....	1
1.2 PRINCIPLE OF MEASUREMENT .....	1
1.3 APPLICATIONS .....	3
1.4 FEATURES .....	3
1.5 SPECIFICATIONS .....	4
1.6 PARTS IDENTIFICATION .....	5
<b>PART-2 TRANSDUCER INSTALLATION .....</b>	<b>6</b>
2.1 GENERAL .....	6
2.2 MOUNTING LOCATION .....	6
2.3 TRANSDUCER SPACING .....	7
2.4 TRANSDUCER MOUNTING .....	9
2.5 TRANSDUCER MOUNTING INSPECTION AND COUPLANT APPLICATION .....	13
<b>PART-3 START OPERATING INSTRUCTIONS .....</b>	<b>14</b>
3.1 POWER ON .....	14
3.2 TRANSMITTER CONNECTIONS .....	14
3.3 KEYPAD FUNCTIONS .....	16
3.4 PIPE PARAMETER ENTRY SHORTCUTS .....	17
<b>PART-4 WINDOWS DISPLAY EXPLANATIONS .....</b>	<b>18</b>
<b>PART-5 ENERGY FUNCTION .....</b>	<b>30</b>
5.1 INTRODUCTION .....	30
5.2 WIRING CONNECTION .....	31
5.3 ENERGY CALCULATION .....	31
5.4 TEMPERATURE RANGE .....	31
<b>PART-6 TEMPERATURE SENSOR INSTALLATION .....</b>	<b>32</b>
6.1 PT1000 TEMPERATURE SENSOR .....	32
6.2 TEMPERATURE SENSOR INSTALATION .....	32
(a) 6.2.1 CLAMP-ON TEMPERATURE SENSOR .....	32
(b) 6.2.2 INSERTION TEMPERATURE SENSOR .....	32
<b>PART-7 HOW TO USE MENU FUNCTIONS .....</b>	<b>34</b>
7.1 HOW TO JUDGE THE LIQUID FLOWING DIRECTION .....	34
7.2 HOW TO RESET THE DEFAULT SETUPS .....	34
7.3 HOW TO STABILIZE THE FLOW .....	34
7.4 HOW TO USE THE LOW FLOW-CUTOFF FUNCTION .....	34
7.5 HOW TO SETUP A ZERO POINT CALIBRATION .....	34
7.6 HOW TO USE SCALE FACTOR .....	35
7.7 HOW TO USE THE 4-20M A OUTPUT .....	35
7.8 HOW TO USE THE RELAY OUTPUT .....	35

7.9 HOW TO USE PULSE OUTPUT .....	36
7.10 HOW TO SET THE DATE AND TIMER .....	36
7.11 ON/OFF NET TOTALIZER .....	36
7.12 UNITS OPTIONS .....	36
7.13 LCD BACKLIT OPT IONS .....	36
7.14 USE MENU WINDOWS FOR TRANSDUCER MOUNTING INSPECTION .....	36
<b>PART-8 FREQUENTLY ASKED QUESTIONS AND ANSWERS .....</b>	<b>38</b>
<b>PART-9 WARRANTY AND SERVICE .....</b>	<b>39</b>
9.1 WARRANTY .....	39
9.2 SERVICE .....	39
<b>APPENDIX 1 MODBUS-RTU COMMUNICATIONS PROTOCOL .....</b>	<b>40</b>
<b>APPENDIX 2 DATA LOGGER .....</b>	<b>45</b>
<b>APPENDIX 3 FUILD CHARACTERISTIC (SOUND SPEED) .....</b>	<b>46</b>
1. FLUID PROPERTIES .....	46
2. WATER SOUND SPEED .....	48
3. PIPE MATERIAL SOUND SPEED TABLE .....	48

## PART-1 INTRODUCTION

### 1.1 GENERAL

It is the engineers and technicians' hope to measure the flow on the non-invasive pipeline reliably. Series TF1100 are state-of-the-art universal transit-time ultrasonic flow meters, fit to measure flow of full pipe line, providing a measuring system with unsurpassed accuracy, versatility, ease of installation and dependability. Although designed primarily for cleaner liquids, the flow meter is tolerant of liquids with the small amount of air bubbles or suspended solids found in most industrial environments.

### 1.2 PRINCIPLE OF MEASUREMENT

The TF1100 ultrasonic flow meter is designed to measure the fluid velocity of liquid within a closed pipe. The transducers are a non-invasive, clamp-on type, which will provide benefits of non-fouling operation and easy installation.

The TF1100 transit time flow meter utilizes two transducers that function as both ultrasonic transmitters and receivers. The transducers are clamped on the outside of a closed pipe at a specific distance from each other. The transducers can be mounted in V-method where the sound transverses the pipe twice, or W-method where the sound transverses the pipe four times, or in Z-method where the transducers are mounted on opposite sides of the pipe and the sound crosses the pipe once. This selection of the mounting method depends on pipe and liquid characteristics. The flow meter operates by alternately transmitting and receiving a frequency modulated burst of sound energy between the two transducers and measuring the transit time that it takes for sound to travel between the two transducers. The difference between the transit-time is directly and exactly related to the velocity of the liquid in the pipe, as shown in Figure 1.




Figure 1

$$V_f = Kdt / TL$$

Where:  $V_f$  Liquid velocity  
 $K$  Constant

$dt$  Difference in time of flight

$TL$  Average Transit Time

When measuring temperature, the two temperature sensors of Pt1000 clamp on the pipeline or insert in the pipe, and get two temperature values.

The value of energy is indicated / measured based on the following mathematical model:

$$Q = \int_{V1}^{V2} k(t1 - t2) dV$$


Where:  $Q$  – Quantity of heat given up

$V$  – Volume of liquid passed

$k$  – Heat coefficient, is a function of the properties of the heat-conveying liquid at the relevant temperatures and pressure

$t1$  – Inlet temperature of liquid

$t2$  – Outlet temperature of liquid



### 1.3 APPLICATIONS

1. Water, sewage (with low particle content) and sea water
2. Water supply and drainage water
3. Process liquids; Liquors
4. Milk, yoghurt milk
5. Gasoline kerosene diesel oil
6. Power plant
7. The flow patrolling and examining
8. Metallurgy, Laboratory
9. Energy-conservation, economize on water
10. Food and medicine
- 11 Heat measures, Heat balance
- 12 On-the-spot check-up, standard, the data are judged, Pipeline leak detection

### 1.4 FEATURES

- 50-hour battery (rechargeable), color LCD display all integrated into a rugged, watertight enclosure.
- Data logger function can be optional.
- Digital cross-correlation technology.
- Non-invasive transducer not contact the liquid, fouling and maintenance are eliminated.
- Clear, user-friendly menu selections make TF1100 simple and convenient to use.
- A pair of sensors can satisfy different materials, wide different pipe diameters.
- Built-in large capacity memory and USB data download function.
- The heat measurement function by configuring with paired Pt1000 temperature sensors.
- Wide bi-directional flow range and wide liquid temperature range: -35°C~200°C.
- Lightweight and easily transportable in box.

## 1.5 SPECIFICATIONS

### Specifications: Transmitter

Measurement principle	Ultrasonic transit-time difference correlation principle
Flow velocity range	0.01 to 12 m/s, bi-directional
Resolution	0.25mm/s
Repeatability	0.2% of reading
Accuracy	±1.0% of reading at rates >0.3 m/s);±0.003 m/s of reading at rates<0.3 m/s
Response time	0.5s
Sensitivity	0.003m/s
Damping of displayed value	0-99s (selectable by user)
Liquid Types Supported	Both clean and somewhat dirty liquids with turbidity <10000 ppm
Power Supply	AC: 85-265V up to 50 hours with full charged internal battery
Enclosure type	Portable
Degree of protection	IP66
Operating temperature	-20℃ to +60℃
Housing material	ABS
Measurement Channels	1
Display	4.3" color LCD display, 18keys
Units	User Configured (English and Metric)
Rate	Rate and Velocity Display
Totalized	gallons, ft³, barrels, lbs, liters, m³,kg
Communication	4~20mA,OCT, Relay, RS485 (Modbus),Logged data
Size	270X215X175mm
Weight	3kg

### Specifications:

#### Transducer (clamp-on)

Degree of protection	IP65 according to EN60529 (IP67 or IP68 upon request)
Suited liquid Temperature	-35℃~200℃
Pipe diameter range	20-50mm for type B, 40-5000mm for type A
Transducer Size	Type B 40(h)*24(w)*22(d)mm Type A 46(h)*31(w)*28(d)mm
Material of transducer	Aluminum + peek
Cable Length	Std: 5m
Temperature Sensor	PT1000 clamp-on

## 1.6 PARTS IDENTIFICATION



Transmitter



Standard Transducer



PT1000 clamp-on



PT1000 insertion



Output Cable



charging cable



S-S Belt



Couplant



SD card reader



## PART-2 TRANSDUCER INSTALLATION

### 2.1 GENERAL

The transducers that are utilized by the Series TF1100 contain piezoelectric crystals for transmitting and receiving ultrasound signals through walls of liquid piping systems. The transducers are relatively simple and straight-forward to install, but spacing and alignment of the transducers is critical to the system's accuracy and performance. Extra care should be taken to ensure that these instructions are carefully executed.

Mounting of the clamp-on ultrasonic transit time transducers is comprised of three steps:

Selection of the optimum location on a piping system.

Entering the necessary parameters into the TF1100 keypad.

(TF1100 will calculate proper transducer spacing based on these entries (menu 25))

Pipe preparation and transducer mounting.

### 2.2 MOUNTING LOCATION

The first step in the installation process is the selection of an optimum location for the flow measurement to be made. For this to be done effectively, a basic knowledge of the piping system and its plumbing is required.

An optimum location is defined as:

**A piping system that is completely full of liquid when measurements are being taken.**

The pipe may become completely empty during a process cycle - which will result in an error code being displayed on the flow meter while the pipe is empty. Error codes will clear automatically once the pipe refills with liquid. It is not recommended to mount the transducers in an area where the pipe may become partially filled. Partially filled pipes will cause erroneous and unpredictable operation of the meter.

**A piping system that contains lengths of straight pipe such as those described in Table 2.1.** The optimum straight pipe diameter recommendations apply to pipes in both horizontal and vertical orientation. The straight runs in Table 2.1 apply to liquid velocities that are nominally 7 FPS [2.2 MPS]. As liquid velocity increases above this nominal rate, the requirement for straight pipe increases proportionally.

**Mount the transducers in an area where they will not be inadvertently bumped or disturbed during normal operation.**

**Avoid installations on downward flowing pipes** unless adequate downstream head pressure is present to overcome cavitations in the pipe.







Piping configuration And transducer position	Upstream Dimension	Downstream Dimension
	Pipe Diameters(*)	Pipe Diameters (**)
	10	5
	14	5
	24	5
	30	5
	10	5
	24	10

Table 2.1 Straight Pipe Requirement

## 2.3 TRANSDUCER SPACING

TF1100 transducers are clamped on the outside of a closed pipe **at a specific distance from each other**. The transducers can be mounted in V-mode where the sound transverses the pipe two times, W-mode where the sound transverses the pipe four times, or in Z-mode where the transducers are mounted on opposite sides of the pipe and the sound crosses the pipe once. For further details, reference pictures located under **Table 2.2**. The appropriate mounting configuration is based on pipe and liquid characteristics. Selection of the proper transducer mounting method is not entirely predictable and many times is an iterative process. **Table 2.2** contains recommended mounting configurations for common applications. These recommended configurations may need to be modified for specific applications if such things as aeration, suspended solids or poor piping conditions are present. W-mode provides the longest sound path length between the transducers - but the weakest signal strength. Z-mode provides the strongest signal strength - but has the shortest sound path length. On pipes smaller than 3 inches [75 mm], it is desirable to have a longer sound path length, so that the differential time can be measured more accurately.

**Table 2.2**  
**Transducer Mounting Modes**


Transducer Mount Mode	Pipe Material	Pipe Size	Liquid Composition
<b>V-Mode</b>	Plastic Metal	1-30 in. (20-750 mm) 2-24 in. (50-600 mm)	Low TSS; non-aerated
<b>Z-Mode</b>	Plastic Metal	> 12 in. (> 300 mm) > 8 in. (> 200 mm) or < 4 in. (< 100 mm)	Low TSS; non-aerated
<b>W-Mode</b> not recommend	Plastic Metal	1-4 in. ( 20-100mm ) 1-4 in. ( 20-100mm )	Low TSS; non-aerated

TSS= Total Suspended Solids


*Plastic includes all pipe material such as PVC, PP, PTFE, PVDF, etc.*

*Metal includes all pipe material such as SS, steel, copper, aluminium, etc, etc.*


### Transducer Mounting Modes



V method



Z method



W method

The TF1100 system calculates proper transducer spacing by utilizing piping and liquid information entered by the user.

The following information is required before programming the instrument. Note that much of the data relating to material sound speed, viscosity and specific gravity are preprogrammed into the TF1100 flow meter. This data only needs to be modified if it is known that a particular liquid data varies from the reference value. Refer to Part 3 of this

manual for instructions on entering configuration data into the TF1100 flow meter via the meter keypad. Transducer mounting configuration. See Table 2.2

1. Pipe Outer Diameter)
2. Pipe wall thickness
3. Pipe material
4. Pipe sound speed
5. Pipe relative roughness
6. Pipe line thickness
7. Pipe line material
8. Pipe line sound speed
9. Fluid type
10. Fluid sound speed


Nominal values for these parameters are included within the TF1100 operating system. The nominal values may be used as they appear or may be modified if exact system values are known.

After entering the data listed above, the TF1100 will calculate proper transducer spacing for the particular data set. This distance will be in inches if the TF1100 is configured in English units, or millimeters if configured in metric units.

## 2.4 TRANSDUCER MOUNTING

After selecting an optimum mounting location and successfully determining the proper transducer spacing, the transducers may now be mounted onto the pipe.

The transducers must be properly oriented on the pipe to provide optimum reliability and performance. On horizontal pipes, the transducers should be mounted 180 radial degrees from one another and at least 45 degrees from the top-dead-center and bottom-dead-center of the pipe. See Figure 2.1. Figure 2.1 does not apply to vertically oriented pipes. On vertical pipes the orientation does not apply.



**Figure 2.1**  
**Transducer Orientation—Horizontal Pipes**


## Pipe Preparation

Before the transducers are mounted onto the pipe surface, two areas slightly larger than the flat surface of the transducer heads must be cleaned of all rust, scale and moisture. For pipes with rough surfaces, such as ductile iron pipe, it is recommended that the pipe surface be ground flat. Paint and other coatings, if not flaked or bubbled, need not be removed. Plastic pipes typically do not require surface preparation other than soap and water cleaning.

Observe Signal Strength while placing the transducers into position. Signal Strength can be displayed on Menu RSSI.


## V-Mode and W-Mode Installation

1. For TF1100 transducers, place a single bead of couplant, approximately 1.2 mm thick, on the flat face of the transducer. Generally, silicone-based grease is used as an acoustic couplant, but any grease-like substance that is rated not to “flow” at the temperature that the pipe may operate will be acceptable.



**Figure 2.2**

2. Place the upstream transducer in position and secure with a mounting strap. Straps should be placed in the arched groove on the end of the transducer. A screw is provided to help hold the transducer onto the strap. Verify that the transducer is stick to the pipe - adjust as necessary. Tighten the transducer strap securely.
3. Place the downstream transducer on the pipe at the calculated transducer spacing. See **Figure 2.3**. Using firm hand pressure, slowly move the transducer both towards and away from the upstream transducer while observing Signal Strength. Clamp the transducer at the position where the highest Signal Strength is observed. A Signal Strength (RSSI) between 60 and 95 is acceptable.
4. If after adjustment of the transducers the Signal Strength (RSSI) does not rise to above 60, then an alternate transducer mounting method should be selected. If the mounting method was W-mode, then reconfigure the TF1100 for V-mode, reset the TF1100, move the downstream transducer to the new location and repeat step 3.



**Figure 2.3** Transducer position

V-Mount is the STD installation method, it is convenient and accurate, Reflective type (transducers mouthed on one side of the pipe) of installation used primarily on pipe size in the (50mm~400mm) internal diameter range attention transducer designed parallel on the centre line of installing the pipeline.

The spacing value shown on menu refers to the distance of inner spacing between the two transducers. The actual transducers spacing should be as close as possible to the spacing value. The transducer spacing is from the end of one transducer to another sensor.


The transducer mounting spacing is very important for Transit-time meters, and users need mount transducers exactly according to the spacing distance value displays after users input proper parameter settings. Pls note the distance is only for reference, and just keep it within 97--103 value range.

As the above figure shows, the normal transducer spacing refers to the distance between the ends of the two transducers (one pair). And this spacing should be according to the value Menu tells you. Note that this method suits for normal Small, Std. M transducer.


### **Mounting Transducers in Z-Mount Configuration**

Installation on larger pipes requires careful measurements to the linear and radial placement of the L1 transducers. Failure to properly orient and place the transducers on the pipe may lead to weak signal strength and/or inaccurate readings. The section below details a method for properly locating the transducers on larger pipes. This method requires a roll of paper such as freezer paper or wrapping paper, masking tape and a marking device.

1. Wrap the paper around the pipe in the manner shown in **Figure 2.4**. Align the paper ends to within 6 mm.
2. Mark the intersection of the two ends of the paper to indicate the circumference. Remove the template and spread it out on a flat surface. Fold the template in half, bisecting the circumference. See **Figure 2.5**.



**Figure 2.4**  
Paper Template Alignment



**Figure 2.5**  
Bisecting the pipe circumference

3. Crease the paper at the fold line. Mark the crease. Place a mark on the pipe where one of the transducers will be located. See **Figure 2.1** for acceptable radial orientations. Wrap the template back around the pipe, placing the beginning of the paper and one corner in the location of the mark. Move to the other side of the pipe and mark the pipe at the ends of the crease. Measure from the end of the crease directly across the pipe from the first transducer location) the dimension derived in Step 2, Transducer Spacing. Mark this location on the pipe.

4. The two marks on the pipe are now properly aligned and measured.

If access to the bottom of the pipe prohibits the wrapping of the paper around the circumference, cut a piece of paper to these dimensions and lay it over the top of the pipe.

Length = Pipe O.D. x 1.57; width = Spacing determined on page 2.6

Mark opposite corners of the paper on the pipe. Apply transducers to these two marks.


5. Place a single bead of couplant, approximately 1.2 mm thick, on the flat face of the transducer. See **Figure 2.2**. Generally, a silicone-based grease is used as an acoustic couplant, but any grease-like substance that is rated to not “flow” at the temperature that the pipe may operate at, will be acceptable.

a) Place the upstream transducer in position and secure with a stainless steel strap or other. Straps should be placed in the arched groove on the end of the transducer. A screw is provided.

b) Try to help hold the transducer onto the strap. Verify that the transducer is true to the pipe - adjust as necessary. Tighten transducer strap securely. Larger pipes may require more than one strap to reach the circumference of the pipe.

6. Place the downstream transducer on the pipe at the calculated transducer spacing. The installation of a pair of sensors is used as an example. The method of the other pair is the same. See **Figure 2.6**. Using firm hand pressure, slowly move the transducer both towards and away from the upstream transducer while observing Signal Strength. Clamp the transducer at the position where the highest Signal Strength is observed. Signal Strength RSSI of between 60 and 95 percent is acceptable. On certain pipes, a slight twist to the transducer may cause signal strength to rise to acceptable levels.

7. Secure the transducer with a stainless steel strap or other.



**Figure 2.6 Z-Mode transducer placements**

## 2.5 TRANSDUCER MOUNTING INSPECTION AND COUPLANT APPLICATION

### 2.5.1 Transducer Mounting Inspection

It is very important to use menu operations for TRANSDUCER MOUNTING INSPECTION and Estimation, Refer to 5.16, Use menu windows for Transducer Mounting Inspection.

### 2.5.2 Couplant Application

**A, It is also very important for couplant application.**

When mounting the transducers, apply just enough pressure so that the couplant fills the gap between the pipe and transducer. Commonly, the Dow 732 for permanent and Dow 111 for temporary installations, but Dow 111 has a better coupling effect. If Dow 732 was used, ensure that no relative movement between the transducer and the pipe takes place during the setting time and do not apply instrument power for at least 24 hours, Dow 111 also be used for permanent installations(avoid rain or water etc.), setting time is not necessary. We recommend using Dow 111 for permanent installing, and then use Dow732 around the transducer in order to fix the transducer, waterproof cloth is recommended if the Transducers are installed outdoor. Dow 112 for high temperature application.

### **B, Transducers for High Temperature**

Mounting of high temperature transducers is similar to TF1100 standard transducers; High temperature installations require acoustic couplant Dow Corning 112 that is rated not to flow at the temperature that will be present on the pipe surface.



## PART-3 START OPERATING INSTRUCTIONS

### 3.1 POWER ON

Press the ON key to switch on the instrument and press the OFF to turn off the power.

Once the flow meter is switched on, it will run a self diagnostic program, checking first the hardware and then the software integrity. If there is any abnormality, corresponding error messages will display.

Generally, there should be no display of error messages, and the flow meter will go to the most commonly used Menu Window to display the Velocity, Flow Rate, Positive Totalizer, Signal Strength and Signal Quality, meter run status based on the pipe parameters configured last time by the user or by the initial program.


The flow measurement program always operates in the background of the user interface. This means the flow measurement will keep on running regardless of any user menu window browsing or viewing. Only when the user enters new pipe parameters will the flow meter change measurement to the new parameter changes.

When new pipe parameters have been entered or when the power has been just switched on, the flow meter will enter an adjusting mode to make the signals magnified with proper amplification. By this step, the flow meter is going to find the best threshold of receiving signal. The user will see the progress by the number 1, 2, or 3, which are indicated on the right lower corner of the LCD display.

When the transducers have been adjusted on the pipe by the user, the flow meter will re-adjust the signal automatically.

Any user-entered configuration value will be retained into the NVRAM of the flow meter, until it is modified by the user.

### 3.2 TRANSMITTER CONNECTIONS



The connectors TF1100 are pluggable type - they can be removed wired and then plugged back in. Connect the appropriate wires to the corresponding connector in the transmitter. Observe UP/DN transducers orientation, the status of the two pairs of transducers are equal. There is no need to specify the transmitting and receiving transducers. (if flow rate display negative, exchange the UP/ DN wiring).

For TF1100-EP, pls connect the two transducers with UP1/DN1.

UP2/DN2 is only for TF1100-DP dual-channel ultrasonic flowmeter TF1100-DP.

T1 and T2 are used for PT1000 temperature sensor wires. T1 is for inlet pipe and T2 is for outlet pipe.




OUTPUT connector is for output 4-20mA, OCT and relay, pls check below wires connection table.

Color	Description
Brown	4-20mA+
Red	4-20mA-
Yellow	OCT +
Black	OCT -
Green	Relay +
Blue	Relay -

Note:

1. The 4-20 mA and Relay output do not requires power from an external DC power supply.
2. The pulse output can only be output by hardware OCT or relay. It requires a 10 k  $\Omega$  pull-up resistor and an external 24V power supply. The wiring diagram is as below.



RS485 connector is for output RS485 Modbus RTU, pls check below wires connection table.

Color	Description
Green	RS485 A
Blue	RS485 B
Black	GND

### 3.3 KEYPAD FUNCTIONS

After transducer and connection of appropriate power supply to TF1100, keypad configuration of the instrument can be undertaken. Generally, there should be no display of error messages, and the flow meter will go to the most commonly used Menu to display the Velocity, Flow Rate, Positive Totalizer, Signal Strength and Signal Quality, based on the pipe parameters entering by the user or by the initial program.

The TF1100 contains a 18-key tactile keypad, allows the user to view and change configuration parameters as shown below.

Follow these guidelines when using TF1100 keypad:

**ON** key: Turn on the flow meter.


**OFF** key: Turn off the flow meter.

**0~9** and **.** to input numbers and decimal.

**CLR** to backspace or delete characters to the left.

The ARROW keys **8** (up arrow) and **2** (down arrow) To return to the last menu or to open the next menu, are used to

scroll through menu configuration parameters; also acts as “+” and “-” functions when entering numbers.



The **ESC** key is used to exit the current screen;

The **ENT** key is confirm key, it is used to "confirm" that a number or selection has been entered. Another function is to enter the "Modify" state before entering parameters.

The **F** key is function key, it used to view the heat value, temperature, CH TX-Time.

**SD** card slot: Used to insert data memory card for data logger function.

**CHAR**: Connect the Type C interface to charge the meter.

### 3.4 PIPE PARAMETER ENTRY SHORTCUTS

The following parameters should be entered for normal measurement:

- a. Pipe outer diameter
- b. Pipe wall thickness
- c. Pipe material
- d. Liner material parameters (including thickness and sound velocity, if needed)
- e. Fluid type
- f. Transducer type (The transmitter is available for various transducer types, for clamp on flow meter to select A or B type, for insertion flow meter to select Plug-in type B )
- g. Transducer mounting methods (refer to **Part 2, W, V, Z**)
- h. For the TF1100 series flow meter, the meter displayed the transducers spacing (two transducers installing distance) should be strictly abode. Also user shall refer to menu TX-Time Rate and keep the value between 97 to 103. and he normal working condition is signal strength RSSI  $\geq 60.0$  and signal quality Q value  $> 40$ .**

In the order stated above, enter the above-mentioned parameters by the following keypad shortcuts:

1. Press **ENTER** key to enter Menu Site Setup, and enter the Pipe Parameter, and then press the **ENTER** key to enter the Outer Diameter.
2. Press the ☐ key to enter pipe wall thickness, and press **ENTER** key.
3. Press the ☐ key to enter Lining Thickness, and press **ENTER** key.
4. Press the ☐ key to select pipe material, and press the **ENTER** key.
5. Press the ☐ key to select liner material, and press the **ENTER** key.
6. Press the ☐ key to select fluid type, and press the **ENTER** key.
7. Press the ☐ key to select transducer type, and press the **ENTER** key.
8. Press the ☐ key to select transducer-mounting method, and press the **ENTER** key.
9. Skip the menus of Zero Adjust,Damping Set,Empty Pipe Set,Measure CHAN Set,Static

Zero Reset, Liquid Temperature as default to factory Settings.

10. Press the ☐ key to check menu Sensor Distance, accurately install the transducer according to the displayed transducer mounting spacing and the selected mounting method (Refer to Installing the Transducers in Part 2).

9. Press the ☐ keys to wait for few seconds of parameters update.

10. Press the ☐ and then ☐ keys to check the CH1 and CH2 ( CH2 only for dual-channel flowmeter) TX-Time Rate and RSSI and Q value.

## PART-4 WINDOWS DISPLAY EXPLANATIONS

### TF1100 Window Descriptions

When reading this section, please refer to the meter menu one by one for easy understanding

The quick way to check display window is to press the ESC key and then press ENT key to check initial Settings.

### Windows Display Explanations

## Main menu window

Window Display	Flow / Total Flow Display	CH	Output Setup	Current Loop Output	CL Output
		RSSI			CL Calibration / CL Output Checkup
		Positive, negative, net total flow			Current Loop Output
		Time/ Flow			CL Mode
		Velocity			Min Output/Max Output
Site Setup	Pipe Parameter	Outer Diameter		SD Card Output	Current Output
		Wall Thickness			Logger Output
		Lining Thickness			Logger Interval
		Inner Diameter	NB Output	NB Output	
		Pipe MAT./Liner MAT.		NB Report Type	
		Kind Of Fluid/Sensor Type/Sensor Mounting		Period Start Time	
		Zero Adjust/Damping Set		Period Interval	
		Empty Pipe Set		Regular Report 1/2/3/4	
		Measure CHAN Set	System Setup	Date	
		Static Zero Reset		Time	
		Liquid Temperature		Backlight	
		Sensor Distance		Language Set	
	Flow Unit Set	Flow Unit Set	F button	Net Energy	
		Totalizer Set		Pos Energy	
		Totalizer Factor		Neg Energy	
	Totalizer Set	Positive Totalizar		Curr NRG	
		Negative Totalizer		T1/T2	
		Totalizer Reset		Transit-Time	
	Flow Cut-off   m/s	Reynolds			
	Flow Scale Factor	CH1 TX-Time Rate			
	Energy Measuring Set	Energy Measuring		Energy Measuring	CH2 TX-Time Rate (for dual-channel flowmeter)
		Energy Unit SET	Device SN		
		Net totalizer	Version		
		Positive Totalizar/Negative Totalizer	Work Time		
		Totalizer Factor			
		Input Temp Calib			
		Output Temp Calib			
		Temp Cut-off			
		SHC			
Output Setup	Modbus Output	Modbus Address Set			
		Baudrate Set			
		Parity Set			
		Stop Bit			
	Relay Output	Relay Output			
		Relay Type			
		Relay Flow Unit			
		Relay Energy Unit			
	Pulse Output	Pulse Output			
		Pulse Type			
		Pulse Flow Unit			
		Pulse Enerav Unit			

Positive total / negative total / net total / flow / Velocity / channel number(only for dual-channel flow meter TF1100-DC/DI) / RSSI, Q value / time

Display positive total flow, negative total flow, net total flow, instantaneous flow and velocity, upstream and downstream signal strength RSSI, signal quality Q value and time.

Signal strength is expressed in numbers from 0 to 99.9. 00.0 indicates that no signal is received and 99.9 indicates that the maximum signal is received. Under normal working conditions, the signal strength RSSI should be  $\geq 60.0$ .

The signal quality Q value is represented by numbers from 00 to 99, 00 is the worst and 99 is the best. The normal working condition is the signal quality Q value  $> 40$ .

When installing and using the flowmeter, the signal strength and quality value need to be as high as possible. Good signal strength and Q value, can ensure the flow meter long-term stable operation and good measurement accuracy.

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:12
Net Total	:	133.989	m <sup>3</sup>
Pos Total	:	138.448	m <sup>3</sup>
Neg Total	:	4.459	m <sup>3</sup>
Flow	:	15.890	m <sup>3</sup> /h
Velocity	:	0.5678	m/s

If the user turns off the net total flow, the value of the net total flow displayed is the value before it is turned off. The net total flow= positive total flow- negative total flow.

### Host Menu Window

Site setup/Output Setup/system Setup/factory Setup

This window is only used to set the parameters of the flowmeter. To access the host menu window, first type ESC and then ENT from the screen.

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:22
Site Setup			
Output Setup			
System Setup			
Factory Setup			

### Site Setup Window

Pipe parameter/ Flow unit set/ Totalize set/ Flow cut-off/ Flow scale factor/ Energy

## Measuring Set

This window is used for setup pipe, flow, totalize, energy and other related parameters. By using ↑ and ↓ keys, you can select the corresponding function and enter ENT for selection or modification.

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:37
Pipe Parameter			
Flow Unit Set			
Totalizer Set			
Flow Cut-off:		0.00001m/s	
Flow Scale Factor:		0.90800	

## Pipe Parameter Menu

Outer Diameter/ Wall Thickness /Lining Thickness/ Inner Diameter/ Pipe MAT/Liner MAT/ Kind Of Fluid/ Sensor Type/ Sensor Mounting/ Zero Adjust/ Damping Set/ Empty Pipe Set/ Measure CHAN Set/ Static Zero Reset/ Liquid Temperature/ Sensor Distance

This window is used for parameter setting, installation and debugging on site. Use ↑ and ↓ to select the corresponding function and type ENT for modification. And then type ENT again for saving.

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:56
Outer Diameter:		108.0mm	
Wall Thickness:		4.0mm	
Lining Thickness:		0.0mm	
Inner Diameter:		100.0mm	
Pipe MAT: Carton Steel			

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:58
Liner MAT:No Liner			
Kind Of Fluid:Water			
Sensor Type:Standard-M			
Sensor Mounting:V Method			



Zero Adjust:Static

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:58
Damping Set : 10			
Empty Pipe Set: 60			
Measure CHAN Set: CH1			
Static Zero Reset: Off			
Liquid Temperature:		20.0 C	

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:36:58
Sensor Distance:		82.76mm	

## Outer Diameter

This menu for entering/changing the outside (outer) diameter of the pipe line. 0 to 6000 mm is the allowed range of the value. Enter the outside diameter size, type ENT for save.

*Note: The outer diameter of the insertion sensor must be more than 65mm.*

## Wall Thickness

The menu for entering pipe wall thickness.

## Lining Thickness

The menu for selecting the liner thickness.

## Inner Diameter

This menu for inside(inner) diameter of the pipe. It is not necessary to enter, automatically calculate and display from outer diameter and pipe wall thickness, it can't be changed.

## Pipe MAT

Menu for selecting pipe material, familiar pipe materials include: (The materials must be equable, compact and can transmit ultrasound)

0. Carbon steel    1. Stainless steel    2. Cast iron    3. Ductile iron    4. Copper  
5. PVC    6. Aluminum    7. Asbestos    8. Fiberglass    9. Others

Item 9 Other is used to enter other materials not included in the 1- 8 items. If the

user selects this option, the corresponding sound speed for the pipe must be entered in the window.

### **Liner MAT**

The menu for selecting the liner material, select 0. No liner if pipe without any liner. familiar liner materials include:

- |               |                |               |                 |                  |
|---------------|----------------|---------------|-----------------|------------------|
| 0. No liner   | 1. Tar Epoxy   | 2. Rubber     | 3. Mortar       | 4. Polypropylene |
| 5. Polystyrol | 6. Polystyrene | 7. Polyester. | 8. Polyethylene | 9. Ebonite       |
| 10. Teflon    | 11. Others     |               |                 |                  |

Item 11 Others is used to enter other materials not included in the 1- 10 items. If the user selects this option, the corresponding sound speed for the liner material must be entered in the window.

### **Kind Of Fluid**

Menu for selecting fluid type

familiar liquids types include:

- |                 |                    |                  |               |               |    |
|-----------------|--------------------|------------------|---------------|---------------|----|
| 0. Water        | 1. Sea Water       | 2. Kerosene      | 3. Gasoline   | 4. Fuel oil   | 5. |
| Crude Oil       | 6. Propane at -45℃ | 7. Butane at 0℃  | 8. Diesel Oil | 9. Caster Oil |    |
| 10 . Peanut Oil | 11. #90 Gasoline   | 12. #93 Gasoline | 13. Alcohol   | 14. Hot       |    |
| water at 125 °C | 15. Others         |                  |               |               |    |

Item 15 Others is used to enter other fluid not included in the 0- 14 items. If the user selects this option, the corresponding sound speed for the liquid must be entered in the window.

### **Sensor Type**

This menu is for selecting the proper sensor type. There are different types of sensors for. For TF1100 series

- |                        |                   |
|------------------------|-------------------|
| 0. Standard-S          | 4. B-HT           |
| 1. Standard-M          | 5. Plug-in Type B |
| 2. Standard-L (delete) | 6. Plug-in Type C |
| 3. A-HT                | 7. User's         |

If the user selects 7 user's, sensor parameters including: Angle of acoustic wedge, acoustic wedge speed, ultrasonic delay time, distance between the center of the acoustic beam and the edge of the sensor must be entered. Please contact Lanry Instruments for specific usage method. Plug-in Type B is for standard Insertion sensor 65-6000mm.

### **Sensor Mounting**

Menu for selecting the sensor mounting method. Four methods can be selected:

0. V-method    1. Z-method    2. N-method    3. W-method

### **Zero Adjust**

Automatic zero/ manual zero/ static zero/ factory zero

Automatic zero is usually chosen.

### **Damping Set**

Flow rate Damping for displaying a stable read. The input range is 0 to 99.

0 means no damping and 99 means maximum damping. Damping acts as a smooth display of data. The principle is just like a single RC low-pass filter, the damping coefficient value is equivalent to the time constant of the circuit. Default value is 10 seconds; common setup value is 10-30 seconds.

### **Empty Pipe Set**

Empty Pipe Setup, this is very useful for user, Empty pipe line or pipe shaking etc., meter may display error or undesired read, user can setup a Q value less than normal Q value, for example, normal Q value is 60-70, user can enter Empty Pipe Setup value 50, so the meter will display 0 flow rate when Q value is less than 50. In good pipe status, please do not setup this value too small, enter a value of 30~40 in this menu is recommended.

### **Measure CHAN Set**

This menu is based on the application to select the corresponding channel and channel number, type ENT for save.

Channel 1 is working for channel 1, channel 2 is working for channel 2, channel 1+ channel 2 means two channels are working at the same time.

*Note: TF1100-EC/EI series is single ultrasonic flowmeter; channel 2 is can NOT be optional.*

*TF1100-DC/DI series is Dual channel ultrasonic flowmeter; channel 2 is can be optional.*

### **Static Zero Reset**

Set Zero, when the fluid is in the static state, the displayed value is called “static zero point”. When the “Zero Point” is not really at zero, the incorrect read value is going to be added into the actual flow values.

Set static zero must be carried out after the sensors are right installed and the flow inside is in the absolute static state (no liquid moved in the pipe line). Set static zero also is very important step when re-calibrating the meter in lab. Doing this step enhances the measuring accuracy and flow offset can be eliminated.

### **Liquid Temperature**

Display the current pipe temperature, it can be setup according to the site conditions, and

then enter ENT to save the data.

If no temperature sensor is installed, no need to set this parameter.

### Sensor Distance

This menu display the sensors mounting spacing.

Users need mount sensors exactly according to the spacing distance value after users input correct parameter setting. This data is automatically calculate by the flow meter after the user enters the all pipeline parameters.

### Flow Unit Set

This window displays Settings for flow unit, for flow rate unit, totalizer flow unit and totalizer factor.

#### Flow Rate Unit

Press scroll key  $\wedge$  or  $\vee$  to select desired time unit, then press “ENTER” for save .

Flow rate unit can be in

- |                              |           |       |
|------------------------------|-----------|-------|
| 0. Cubic Meters              | short for | (m3)  |
| 1. Liter                     |           | (l)   |
| 2. American Gallon           |           | (gal) |
| 3. Imperial Gallon           |           | (igl) |
| 4. Million Gallon (American) |           | (mgl) |
| 5. Cubic Feet                |           | (cf)  |
| 6. American Liquid Barrel    |           | (bal) |
| 7. Imperial Liquid Barrel    |           | (ib)  |
| 8. Oil Barrel                |           | (ob)  |

The flow unit in terms of time can be per day, per hour, per minute or per second. So there are 36 different flow rate units in total for selection.

#### Totalizer flow unit

Window for selecting Totalizers Unit, working unit default is cubic meters, if change it, press ENTER, then press scroll key  $\wedge$  or  $\vee$ , to select desired unit.

#### Totalizer factor

Select Totalizer Factor (Multiplier)

The multiplier ranges from 0.001 to 10000, default value is  $\times 1$ , addition, if select total flow pulse output, this value represent one pulse corresponding value.

0.  $\times 0.001$  (1E-3)
1.  $\times 0.01$
2.  $\times 0.1$
3.  $\times 1$
4.  $\times 10$

- 5. x 100
- 6. x 1000
- x 10000 (1E+4)

### **Totalizer Set**

Turn on or turn off the NET Totalizer, Positive Totalizer, Negative Totalizer.

### **Positive Totalizer**

This menu is used to turn on or turn off the positive totalizer, the flowmeter positive totalizer accumulates when it is "ON". When it is "Off", the positive totalizer will not change. The factory default is "ON".

### **Negative Totalizer**

This menu is used to turn on or turn off the negative totalizer, the flowmeter negative totalizer accumulates when it is "ON". When it is "Off", the negative totalizer will not change. The factory default is "ON".

### **Totalizer Reset**

This window is used to clear the Totalizer and all set parameters. the following options are available after type ENT:

None

All

Positive

Negative

Take care or make note on the parameters before doing restoration.

### **Flow Cut-off**

Low Flow Cutoff, may be used in order to force a zero display at lower flows and avoid incorrect totalizer.

For instance, this value is 0.02m/s, the meter will display zero when flow rate is less than  $\pm 0.02\text{m/s}$ .

### **Flow Scale Factor**

The Scale Factor is used to modify the measurement results, factory default is 1.0 or other value depend on calibration, please see the calibration data sheet and save this sheet. If really necessary, the user can enter a numerical value other than factory default value according to re-calibration results.

### **Energy Measure Set**

This window is mainly used for parameter setting of energy measurement.

### **Energy Measuring**

This menu is used to turn on or turn off the energy measure. After it is turn on, the energy measurement function is started.

### Energy Unit Set

Energy Flow Unit can be choose as KCAL, KWh and GJ.

Factory default is KWh.

### Positive Totalizer ( Energy )

This menu is used to turn on or turn off the energy positive totalizer, the flowmeter energy positive totalizer accumulates when it is "ON". When it is "Off", the energy positive totalizer will not change. The factory default is "ON".

### Negative Totalizer ( Energy )

This menu is used to turn on or turn off the energy negative totalizer, the flowmeter energy negative totalizer accumulates when it is "ON". When it is "Off", the energy negative totalizer will not change. The factory default is "ON".

### Totalizer Reset ( Energy )

This window is used to clear the energy Totalizer and all set parameters. the following options are available after type ENT:

None

All

Positive

Negative

Take care or make note on the parameters before doing restoration.

### Totalizer factor ( Energy)

Select Energy Totalizer Factor (Multiplier)

The multiplier ranges from 0.001 to 10000, default value is  $\times 1$ , addition, if select total flow pulse output, this value represent one pulse corresponding value.

0.  $\times 0.001 (1E-3)$

1.  $\times 0.01$

2.  $\times 0.1$

3.  $\times 1$

4.  $\times 10$

5.  $\times 100$

6.  $\times 1000$

$\times 10000 (1E+4)$

### Input Temp Calib

Calibrate the input temperature, we have already done the calibration in our laboratory, so customers do not need to calibrate. When the value has been changed or need to re-calibrate, customers can calibrate the value yourselves.

### **Output Temp Calib**

Calibrate the output temperature.

### **Temp Cut-off**

Low temperature difference cutoff.

### **SHC**

SHC is short of specific heat capacity.

The meter default calculate the thermal enthalpy as the water of a certain temperature automatically. If the measure fluid is not water, user need to manually enter the fluid specific heat capacity in the menu SHC.

### **Output Setup**

This window is used for the flowmeter output Setup, the output can be set Modbus output / Relay output / Pulse output / Current loop output / SD card output/ NB output. Select the corresponding output according to the application.

### **Modbus Output**

This menu is used for Modbus Settings as Address/ Baud Rate/ Parity Set/ Stop Bit.

The default address is 1, baud rate is 9600, Parity is None and stop bit is 1.

It can be set according to the site conditions.

### **Relay Output**

This menu is used to set the relay output.

Once the transmitter is powered on, relay output is normally Open state.

### **Pulse Output**

This menu is used for pulse output settings, such as Pulse output, Pulse type, pulse flow unit and pulse energy unit.

### **Current Loop Output**

This window is used to set current loop output turn on or off and related parameters settings.

### **CL Calibration**

This menu is for 4-20mA output calibration, Use a Ammeter to verify 4mA output, use key  $\wedge$  or  $\vee$ , let the output is 4.0mA. Use the same way, let the Output is 20.0mA. This

function mainly used by TF1100 manufacturer.

## CL Output Checkup

This menu is used to check whether the current loop of flow meter has been calibrated well. Enter ENT key and use  $\uparrow$  or  $\downarrow$  to check value of 4mA, 8mA, 12mA, 16mA and 20mA. At the same time, use a precision ammeter to check if the output data correct. If the allowable error is exceeded, the current loop needs to be re-calibrated.

## Current Loop Output and CL mode

4-20mA is the most common output mode.

## Min Output/Max Output

Min Output is used to set the minimum flow value of 4mA or 0mA. Max Output is used to set the maximum flow value of 20mA.

## Current Output

It is for current output display.

If 4.0000mA is displayed, it means that the output value of the current loop is 4.0000mA. If there is a large deviation between the output value and flow meter display, the user should calibrate the current loop.

## Logger Output/Logger Interval

This menu is for data logger output to store measurement data. And the logger time interval can be set up.

## System Setup

This window is used for date, time, backlight, language settings.

## Date and time

Setup the date and time of the meter.

YY-MM-DD (For example, it is Aug 14, 2022 today, the setting should be 22/08/14)

HH-MM-SS (Hour-minute-second, in 24 hour format)

Type ENT and the prompt ">" appears then the date and time can be modify.

## Backlight

LCD contrast control. The LCD will become darker when a small value is entered.

## Language Set

Used to select the display language.

## F button

Enter FUNC function key, press ENT key.

This window for net total, positive total / negative total / flow / velocity;

Net Energy / Pos Energy / Neg Energy/ Current energy / T1 and T2;



Transit-Time / Reynolds / CH1 TX-Time Rate / CH2 TX-Time Rate;

Device SN / Version / work time. As shown in the window below.

CH 1	RSSI=93.0-92.8/95.9-95.6	Q=92.2/93.4	10:38:49
Net Energy:	16000	KWh	
Pos Energy:	16000	KWh	
Neg Energy:	0.000	KWh	
Curr NRG :	229.693	KW	
T1/T2 :	32.40/22.20		

CH 1	RSSI=82.2-82.3/82.1-82.2	Q=72.6/75	10:38:49
Transit-Time :	229.75	us	
Reynolds :	119		
CH1 TX-Time Rate:	99.26		
CH2 TX-Time Rate:	100.98		

CH 1	RSSI=82.2-82.3/82.1-82.2	Q=72.6/75	10:38:49
Device SN:	211150032		
Version:	1.00		
Work Time:	57 hours		

## PART-5 ENERGY FUNCTION

### 5.1 INTRODUCTION

Series TF1100 heat meter owns an in-built module for energy calculation. It can calculate the thermal enthalpy of the water of a certain temperature automatically. Accordingly we can calculate the heat flow and totalizer.


If the measure fluid is not water, user need to manually enter the fluid specific heat capacity in the menu SHC.

All above results can be transferred to host computer through a communication protocol of the flowmeter. In this case, TF1100 heat meter works as data monitoring

network RTU, greatly decrease the complexity, cost and enhancing the reliability of the hardware of devices.

## 5.2 WIRING CONNECTION

The fluid temperature is obtained by an external input Pt1000 platinum resistance temperature sensor signal from outside. When calculating energy, T1 connects to inlet sensor and T2 to outlet sensor.



## 5.3 ENERGY CALCULATION

There are two methods to calculate energy:

Method 1) :  $\text{Energy} = \text{Flow} \times \text{Temp. Difference} \times \text{heat capacity}$  ( Where : Temp. Difference refers to the temperature difference between  $T_{in}$  and  $T_{out}$ .)

Method 2):  $\text{Energy} = \text{Flow} \times (\text{thermal enthalpy at } T_1 \text{ temp.} - \text{thermal enthalpy at } T_2 \text{ temp.})$  This thermal enthalpy is automatically calculated by heat meter according to international standard.

## 5.4 TEMPERATURE RANGE

Temperature range is defined in Menu.

For example, at the condition that when temperature sensor resistance value is  $1000 \Omega$ , temperature is  $0^{\circ}\text{C}$ , and temperature sensor resistance value is  $1758.56 \Omega$ , temperature is  $200^{\circ}\text{C}$ . The temperature values have been calibrated before delivery, so users do not need to set this parameter. If the output value of the platinum resistance temperature sensor is  $1000\Omega$ , the temperature displayed by the flowmeter is  $0^{\circ}\text{C}$ ; If the platinum resistance value is  $1758.56\Omega$ , the displayed temperature is  $200^{\circ}\text{C}$ . Users can check the menu to view the current temperature.

## **PART-6 TEMPERATURE SENSOR INSTALLATION**

### **6.1 PT1000 TEMPERATURE SENSOR**

TF1100 heat meter utilizes two PT1000 temperature sensors, and the temperature sensors are matching. Temperature sensor cable is provided by manufacturer, and the standard length is 10m.

For measurement accuracy, test security, convenient maintenance, and not affect equipment operation and production operation, we should pay attention to the following before installation:

1. Should be rationally choose installation position, avoid the valve, elbow and equipment installed with thermal resistance.
2. For measuring the fluid temperature of pipe center, generally the measurement terminal is inserted into the pipe in the center.

3. Water supply temperature sensor (high temperature point) must be installed in flow transducer downstream side, and is apart from the downstream flow transducer 5DN.

The return water temperature sensor (low temperature point) should choose the position where is in recent from water supply temperature sensor.

### **6.2 TEMPERATURE SENSOR INSTALATION**

#### **(a) 6.2.1 CLAMP-ON TEMPERATURE SENSOR**

When determining the installation position of temperature sensor, we should pay attention to the pipeline surface. Pipeline surface must be clean before installing temperature sensor, then use belts to fix temperature sensor.

#### **(b) 6.2.2 INSERTION TEMPERATURE SENSOR**

The insertion temperature sensor is directly contact with measured fluid, so its accuracy is higher. We have two methods to install insertion temperature sensor.

##### **1. Installing by ball valve**

For wieldable pipe material, weld ball valve on pipe directly. For non-wieldable pipe material,


first welding a hoop (Usually material is carbon steel) on pipe, then welding ball valve on hoop.

After welding ball valve, drill a suitable hole. Drill into the pipe wall in accordance with the instructions supplied with the drilling machine, at first, please select the slow tap position to drill hole, then select fast tap position.

After drilling a hole, plug in the insertion temperature sensor, adjust the insertion depth, then fix it.

## 2. Installing on pipe directly

Drill a suitable hole on pipe directly, plug in the insertion temperature sensor, adjust the insertion depth, and then fix it.



Note: The cables of two temperature sensor must be the same length.

## **PART-7 HOW TO USE MENU FUNCTIONS**

### **7.1 HOW TO JUDGE THE LIQUID FLOWING DIRECTION**

Make sure that the instrument works properly

Check the flow rate for the indication. If the displayed value is positive, the direction of the flow will be from the UP transducer to the Down transducer; if the displayed value is negative, the direction will be from the Down transducer to the UP transducers;

Check the flow rate, if the display value is “+”, will it is positive. If the display value is “-”, It is negative.

### **7.2 HOW TO RESET THE DEFAULT SETUPS**

Press the key ESC and then press ENT to enter, meter will erase all the parameters entered by the user and setup the meter with default values.

### **7.3 HOW TO STABILIZE THE FLOW**

The damping acts as a filter for a stable reading. If ‘0’ is entered in menu, that means there is no damping. A bigger number brings a more stable effect. But bigger damping numbers will prevent the instrument from acting quickly. Numbers 0 to 10 are commonly used for the damping value.

### **7.4 HOW TO USE THE LOW FLOW-CUTOFF FUNCTION**

The number displayed in menu Flow Cut-off is called the low flow cutoff value or zero cutoff value. The flow meter will replace these flow rate values that are absolutely less than the low-cutoff value with ‘0’. This means the flow meter will avoid any invalid accumulation when the actual flow is below the zero-cutoff value.

The low-cutoff value does not affect the flow measurement when the actual flow is absolutely greater than the low-cutoff value.

### **7.5 HOW TO SETUP A ZERO POINT CALIBRATION**

It is necessary to establish the true zero flow condition and program that set point into the instrument. If the zero set point is not at true zero flow, a measurement difference may occur. Because every flow meter installation is slightly different and sound waves can travel in slightly different ways through these various installations, a provision is made in this entry to establish “True Zero” flow – SETUP ZERO.

There exists a ‘Zero Point’ with certain installation which means the flow meter will display a non-zero value when the flow is absolutely stopped. In this case, setting a zero point with the function in menu will bring a more accurate measurement result. When do a calibration test, it is also very important.

Make sure that the pipe is full of liquid and the flow is absolutely stopped - securely close

any valves and allow time for any settling to occur. Then run the function in window Static Zero Reset by press ENT key and wait until the counter readings displayed in the lower right corner of the screen goes to “00” ; thus, the zero set is completed and the instrument indicates the results automatically. Repeat zero set calibration if it still needs to be minimized, i.e. the velocity reading is still high.

## 7.6 HOW TO USE SCALE FACTOR

Scale factor refers to the ratio between “actual value” and “reading value”. For instance, when the measurement is 2.00, and it is indicated as 1.98 on the instrument, the scale factor reading is  $2/1.98$ . This means that the best scale factor constant is 1. However, it is difficult to keep the scale factor as “1” on the instrument especially in batch control operations. The difference is called “consistency”. High quality products always require high consistency.

The scale factor default is “1” or a factory calibration value (see the calibration data sheet for every meter) for each instrument prior to shipment from the factory. The scale factor entered must be one that results from actual calibration. Re-calibration or change the Scale factor may be necessary on different pipe lines or different applications in order to obtain better accuracy.

## 7.7 HOW TO USE THE 4~20M A OUTPUT

Possessing a current loop output exceeding an accuracy of 0.1%, the TF1100 is programmable and configurable with multiple output modules. Select in Window Current Loop Output.

Calibrating and testing the current loop 4mA, 8mA, 12mA, 16mA, and 20mA are performed in the Window. Complete the steps as follows: Press Menu, move  $\wedge$  or  $\vee$  to display “0mA”, “4mA”, “8mA”, “16mA”, “20mA” readings, connect an ammeter to test the current loop output and calculate the difference. Calibrate it if the difference is within tolerance. Check the present current loop output as it changes along with change in flow.

Enter the flow value represented by 4mA and the flow value represented by 20mA in the current loop menu. For example, if the flow rate range is from 0 to 1000m<sup>3</sup>/h, input 0 for the 4mA and input 1000 for the 20mA.

## 7.8 HOW TO USE THE RELAY OUTPUT

To use the relay to output forward cumulative pulses.

For example, to set the pulse equivalent to 1m<sup>3</sup>, the following settings can be made:

Select "Relay output" in the output setting, select "On" for relay output, select "Positive flow" for relay type, and select "1m<sup>3</sup>" for relay flow unit. At this time, the relay will work once for every 1m<sup>3</sup> increase in positive flow.

The appropriate relay data should be set, if it is too large, the output cycle is too long; If it is too small, the relay will operate too frequently, affecting its service life.

## 7.9 HOW TO USE PULSE OUTPUT

Each unit flow detected by the ultrasonic flowmeter generates a cumulative pulse and outputs it to an external pulse counter device. Pulse output is only for Totalizer Output, and it can only be output through OCT or relays. So it is necessary to set the OCT or relay accordingly in the flow meter menu.

For example, to set the positive totalizer to output a pulse for every 10mL increase in water, the setting is as follows:

Select "Pulse output" in the output setting, select "On" for pulse output, select "Positive flow" for pulse type, and select "10mL" for pulse flow unit. At this time, the pulse will work once for every 10mL increase in positive flow.

## 7.10 HOW TO SET THE DATE AND TIMER

The ultrasonic flowmeter adopts the perpetual calendar clock chip produced by RAMTRON, which has high reliability. In general, the date and time need not be modified.

In case of modification, enter the system setting of date and time window and type ENT. When a symbol is displayed on the left side of the downward line of the screen, it indicates the state of modification. Users can modify the time and date.

## 7.11 ON/OFF NET TOTALIZER

Window Totalizer Set is available to turn totalizer on and off.

## 7.12 UNITS OPTIONS

Measurement units options, Metric or English, select Flow Unit Set, Press ESC and then ENTER, and scroll the  $\wedge$  or  $\vee$  to select units;

## 7.13 LCD BACKLIT OPT IONS

Adjustment the backlighting in window , press ENTER, then use  $\wedge$  or  $\vee$  to scroll the menu, to select backlit options.

## 7.14 USE MENU WINDOWS FOR TRANSDUCER MOUNTING INSPECTION

### 7.14.1 Signal Strength

Signal strength (displayed in Window RSSI) indicates a detected strength of the signal both from upstream and downstream directions. The relevant signal strength is indicated by

numbers from 00.0~99.9 in the TF1100. 00.0 represents no signal detected while 99.9 represent maximum signal strength.

Normally, the stronger the signal strength detected, the instrument will work more reliably, as well as the more stable the measurement value obtained.

Adjust the transducer to the best position and check to ensure that enough sonic coupling compounds is applied adequately during installation in order to obtain the maximum signal strength. System normally requires signal strength over 60.0, which is detected from both upstream and downstream directions. If the signal strength detected is too low, the transducer installation position and the transducer mounting spacing should be re-adjusted and the pipe should be re-inspected. If necessary, change the mounting to the Z method.

#### 7.14.2 Signal Quality (Q value)

Q value is short for Signal Quality (displayed in Window). It indicates the level of the signal detected. In the TF1100, Q value is indicated by numbers from 00~99. 00 represents the minimum signal detected while 99 represent the maximum. Normally, the transducer position should be adjusted repeatedly and coupling compound application should be checked frequently until the signal quality detected is as strong as possible.

#### 7.14.3 Total Time and Delta Time

“Total Time and Delta Time”, which displays in Window, indicates the condition of the installation. The measurement calculations in the flow meter are based upon these two parameters. Therefore, when “Delta Time” fluctuates widely, the flow and velocities fluctuate accordingly. This means that the signal quality detected is too poor. It may be the resulted of poor pipe-installation conditions, inadequate transducer installation or incorrect parameter input. Generally, “Delta Time” fluctuation should be less than  $\pm 20\%$ . Only when the pipe diameter is too small or velocity is too low can the fluctuation be wider.

#### 7.14.4 Transit Time Ratio

Transit Time Ratio indicates if the transducer mounting spacing is accurate. The normal transit time ratio should be  $100 \pm 3$  if the installation is proper. Check it in menu CH TX-Time Rate. If the transit time ratio is over  $100 \pm 3$ , it is necessary to check (1) if the parameters (pipe outside diameter, wall thickness, pipe material, liner, etc.) have been entered correctly, (2) if the transducer mounting spacing is accordance with the display in Window, (3) if the transducer is mounted at the pipe’s centerline on the same diameter, or (4) if the scale is too thick or the pipe mounting is distorted in shape, etc.

#### 7.14.5 Warnings

1. Pipe parameters entered must be RIGHT; otherwise the flow meter will not work properly.
2. During the installation, apply enough coupling compounds in order to stick the transducer onto the pipe wall. While checking the signal strength and Q value, move the transducer slowly around the mounting site until the strongest signal and maximum Q value can be obtained. Make sure that the larger the pipe diameter, the more the transducer should be moved. Check to be sure the mounting spacing is accordance with the display in meter and the transducer is mounted at the pipe’s centerline on the same diameter. Pay special



attention to those pipes that formed by steel rolls (pipe with seams), since such pipe is always irregular. If the signal strength is always displayed as 0.00, that means there is no signal detected. Thus, it is necessary to check that the parameters (including all the pipe parameters) have been entered accurately. Check to be sure the transducer mounting method has been selected properly, the pipe is not worn-out, and the liner is not too thick. Make sure there is indeed fluid in the pipe or the transducer is not very close to a valve or elbow, and there are not too many air bubbles in the fluid, etc. With the exception of these reasons, if there is still no signal detected, the measurement site has to be changed.

3 Make sure that the flow meter is able to run properly with high reliability. The stronger the signal strength displayed, the higher the Q value reached. The longer the flow meter runs accurately, the higher the reliability of the flow rates displayed. If there is interference from ambient electromagnetic waves or the signal detected is too poor, the flow value displayed is not reliable; consequently, the capability for reliable operation is reduced.

4 After the installation is complete, power on the instrument and check the result accordingly.

## PART-8 FREQUENTLY ASKED QUESTIONS AND ANSWERS

**Q:** New pipe, high quality material, and all installation requirements met: why still no signal detected?

**A:** Check pipe parameter settings, installation method and wiring connections. Confirm if the coupling compound is applied adequately, the pipe is full of liquid, transducer spacing agrees with the screen readings and the transducers are installed in the right direction.

**Q:** Old pipe with heavy scale inside, no signal or poor signal detected: how can it be resolved?

**A:** Check if the pipe is full of fluid. Try the Z method for transducer installation (If the pipe is too close to a wall, or it is necessary to install the transducers on a vertical or inclined pipe with flow upwards instead of on a horizontal pipe). Carefully select a good pipe section and fully clean it, apply a wide band of coupling compound on each transducer surface (bottom) and install the transducer properly. Slowly and slightly move each transducer with respect to each other around the installation point until the maximum signal is detected. Be careful that the new installation location is free of scale inside the pipe and that the pipe is concentric (not distorted) so that the sound waves do not bounce outside of the proposed area. For pipe with thick scale inside or outside, try to clean the scale off, if it is accessible from the inside. (Note: Sometimes this method might not work and sound wave transmission is not possible because of the a layer of scale between the transducers and pipe inside wall) .

**Q:** Why is the CL output abnormal?

**A:** Check to see if the desired current output mode is set in the flow meter. Check to see if

the maximum and minimum current values are set properly in meter.

**Q:** Why is the flow rate still displayed as zero while there is fluid obviously inside the pipe ?

**A:** Check to see if “Set Zero” was carried out with fluid flowing inside the pipe. If it is confirmed, recover the factory default.

**Q:** With a poor measurement site environment in the plant and the voltage and power supplies fluctuating widely, is the instrument really able to keep running 24 hours a day repeatedly without stopping and last for several years under such conditions?

**A:** TF1100 is designed to work with high reliability under such conditions. It is provided with an intelligent signal conditioning circuit and internal correction circuitry. It will work under strong interference conditions and is able to adjust itself with strong or weak sound waves. It will work in a wide band of voltage: 90-260VAC or 8V~28V DC voltage.

## PART-9 WARRANTY AND SERVICE

### 9.1 WARRANTY

The manufacturer provides one year warranty on all products, free of charge, but the users should be responsible for the one-way transportation fee from the customer to the factory.

### 9.2 SERVICE

The manufacturer provides instrument installation for our customers, and the charges will be made according the cost.

- (1) For any hardware failure of the instrument, we recommend that our customers send back the instrument to our factory for service, due to the fact that the instrument is made of microprocessors and it will be difficult to perform field maintenance. Before sending back the instrument, please try to contact the factory first to make sure what the problem is.
- (2) For other operational problems, please contact our local distributor by telephone, fax or email. In most cases, the problem could be solved immediately.

## APPENDIX 1 MODBUS-RTU COMMUNICATIONS PROTOCOL

TF1100 series ultrasonic flowmeter default Modbus output as Modbus-RTU protocol. The “D+” terminal is connected to RS485 “A”, and “D-” terminal is connected to RS485 “B”.

**When use Modbus-RTU protocol, please refer to the following steps:**

- To enter Output Setup in the menu.
- Select the Modbus Output.
- Enter the meter address, and this address must be the same with modbus address. If users modify the meter address after power on meter, please restart meter.
- Set the baud rate, Parity and stop bit

*The default setting as address is 1, baud rate is 9600, none, and stop bit is 1.*

### A. Communications Protocol

The flow meter supports the Modbus RTU protocol as slave device and communicate with other device by RS485 in usual. It will adhere to the standard read/write message structures and its implementations, note that Modbus does not provide a suitable structure for file transfers.

The general message structure will consist of device address, function code, data payload and the checksum. Data transmission follows big-endian byte order rules.

#### Master Format

Device Address	Function Code	Data Payload	CRC
----------------	---------------	--------------	-----

Device address – 1 byte field ranging from 1 to 255. Broadcast address 0.

Function code – 1 byte field with 3 read operations, 16 write operations.

Data payload – 0-N bytes with response data from the device.

CRC – 2 bytes computed mathematically.

#### Slave Response Format

Device Address	Function Code	Data Payload	CRC
----------------	---------------	--------------	-----

Device Address – Echo of device address sent in master message to the device

Function code – Echo of function code sent in master message to the device

Data payload – 0-N bytes with response from device.

CRC – 2 bytes with a value computed mathematically

### B. Standard Message Format

Read Holding Registers is used to retrieve measurements.

Message	
Address	1 byte
Function Code	1 byte
Data Address	2 bytes
Register Count	2 bytes
CRC	2 bytes

Response	
Address	1 byte
Function Code	1 byte
Byte Count	1 byte
Data Payload	N bytes
CRC	2 bytes

\*Byte count = 2\*Register Count

Write Single Register is used to configure instrument settings.

Message	
Address	1 byte
Function Code	1 byte
Data Address	2 bytes
Register Count	2 bytes
Data Payload	N byte
CRC	2 bytes

Response	
Address	1 byte
Function Code	1 byte
Byte Count	1 byte
Data Payload	N bytes
CRC	2 bytes

### C. RS485 Settings

Baud rates – Support Baud rates from 4800 to 19200

Data Bits – 8 data bits (7 data bits is not valid setting for Modbus RTU)

Parity Bits – Even, Odd and None

Stop Bits – 1

**Default settings will be 9600,8,N,1.**

### D. Modbus Registers

The below list of parameters will all be located in the holding registers.

*Note: All the parameters for CH2 ( channel 2 ) is only for TF1100-DP series dual-channel flowmeter.*

Register Address	Size (byte)	Mode	Data Type	Description
00	4	RO	float	Velocity
02	4	RO	float	Flow
04	8	RO	double	Net Total
08	8	RO	double	Pos Total
12	8	RO	double	Neg Total
16	4	RO	float	T1 Input Value
18	4	RO	float	T2 Input Value
20	4	RO	float	Instant Energy
22	8	RO	double	Net Energy
26	8	RO	double	Pos Energy
30	8	RO	double	Neg Energy
34	4	RO	int	Sensor Distance (mm)
36	4	RO	float	CH1 TX-Time Rate
38	4	RO	float	Channel 1 signal quality (Q)
40	4	RO		Reserve
42	4	RO	float	Channel 1 up signal strength
44	4	RO	float	Channel 1 down signal strength
46	4	RO	float	CH2 TX-Time Rate
48	4	RO	uint	Channel 2 signal quality (Q)
50	4	RO		Reserve
52	4	RO	float	Channel 2 up signal strength
54	4	RO	float	Channel 2 down signal strength

Register Address	Size (byte)	Mode	Data Type	Description
100	4	RO	float	Outer Diameter (mm)
102	4	RO	float	Wall Thickness (mm)
104	4	RO	float	Lining Thickness (mm)
106	4	RO	Int	Pipe MAT
108	4	RO	float	User-defined pipe sound speed (m/s)
110	4	RO	Int	Liner MAT
112	4	RO	float	User-defined liner sound speed (m/s)
114	4	RO	Int	Kind of Fluid
116	4	RO	float	User-defined liquid sound speed (m/s)
118	4	RO	Int	Sensor Type
120	4	RO	Int	User-defined sensor angle
122	4	RO	float	User-defined sensor wedge sound speed (m/s)
124	4	RO	float	User-defined sensor wedge surface center point to sensor edge distance (mm)
126	4	RO	float	User-defined sound wave delay time in a single sensor (us)
128	4	RO	Int	Sensor Mounting
130	4	RO	Int	Measure the minimum signal strength
132	4	RO	Int	Zero calibrate type
134	4	RO	float	User-defined zero offset
136	4	RO	uint	Damping Set
138	4	RW	Int	Volume set in flow unit
140	4	RW	Int	Time set in flow unit
142	4	RW	Int	Totalizer Unit
144	4	RW	Int	Totalizer Factor
146		RW	Int	Postive Totalizer
148		RW	Int	Negative Totalizer
150		RW	float	Flow Cut-off
152		RW	float	Flow Scale Factor
154		RW	Int	Energy Measuring
156		RW	Int	Energy Unit Set
158		RW	Int	Positive Totalizer
160		RW	Int	Negative Totalizer
162		RW	Int	Totalizer Factor
164		RW	float	Input Temp Calib
166		RW	float	Output Temp Calib
168		RW	float	Temp Cut-off
170		WO	Int	Totalizer Reset-Flow
172		WO	Int	Totalizer Reset-Energy
174		RO	Int	Measure CHAN Set

Register Address	Size (byte)	Mode/ Access	Data Type	Description
200	4	RW	Int	Modbus address
202	4	RW	Int	Baudrate Set
204	4	RW	Int	Parity Set
206	4	RW	Int	Relay output
208	4	RW	Int	Relay Type
210	4	RW	Int	Relay Flow Unit
212	4	RW	Int	Relay Energy Unit
214	4	RW	Int	Pulse Output
216	4	RW	Int	Pulse Type
218	4	RW	Int	Pulse Flow Unit
220	4	RW	Int	Pulse Energy Unit
222	4	RW	Int	Current Loop Output
224	4	RW	Int	CL Calibration
226	4	RW	Int	4ma Checkup
228	4	RW	Int	20maCheckup
230	4	RW	Int	CL Mode
232	4			Reserve
234	4	RW	float	Min. Output
236	4	RW	float	Max. Output
238	4	RO	float	Current Output
240	4	RW	Int	Logger Output
242	4	RW	hhmmss	Logger Interval BCD Code
244	4	RW	Int	NB Output
246	4	RW	Int	NB Report Type
248	4	RW	hhmmss	NB Period Start Time BCD Code
250	4	RW	hhmmss	NB Period Interval BCD Code
252	4	RW	hhmmss	NB Regular Report 1, BCD Code
254	4	RW	hhmmss	NNB Regular Report 2, BCD Code
256	4	RW	hhmmss	NB Regular Report 3, BCD Code
258	4	RW	hhmmss	NB Regular Report 4, BCD Code

Register Address	Size(byte)	Mode	Data Type	Description
300	4	RW	yymmdd	Data Set BCD Code
302	4	RW	hhmmss	Time Set BCD Code
304	4	RW	Int	Backlight
306	4	RW	Int	Language Set
308	4	RO	Int	Relay output
310	4	RO	Int	Working Time (hours)

Register Address	Size (byte)	Mode	Data Type	Description
400	4	RW	Int	ESN(Electronic Serial Number)

## APPENDIX 2 DATA LOGGER

### Meter Setting Before Using Data Logger

Before using the data logger, please check the following items of meter settings (otherwise, the data logger will not work normally):

#### I. Time setting

it is time setup for meter, the format should be:

YY-MM-DD (For example, it is January 11th, 2023 today, the setting should be 23/01/11)

HH-MM-SS (Hour-minute-second, in 24 hour format)

#### II. SD card output setting

##### SD card output

To choose “On” for Logger output

#### III. Logger Interval

To set the time interval as your application

The format is as hh:mm:ss ( Hour: Minute: Second)

Recommend to set the time interval longer than 5 seconds.

Then insert the SD card in the meter. The meter will restart, which means the data logger works well.

**IMPORTANT:** Restart the meter is a must before data logger working. Only insert the SD card the meter will not restart, and the data logger will **stop recording data**.

#### IV. Read Data

When downloading data, it will create a new .csv file named for date,, the naming rules of the file is the data storage date. For example,

##### Naming rules of “csv” file

xx( year)-xx(month)-xx(date).csv

23-01-11.CSV

Save another file by naming rules when the “csv” file has recorded 2000 data.

(Default data number: without limit, according to requirement, the number can change, please consult factory)

When opening the “csv” file, the data are shown as below:

Date	Time	Flow	Unit	Vel	Unit	NET	Unit	POS	Unit	NEG	Unit	Energy	Unit	NET	Unit	POS	Unit	NEG	Unit	T_Input[C]	T_Output[C]
11-01-2023	14:10:35	197.59	/h	3.278432	m/s	8.760329	m3	9.69971	m3	0.939381	m3	10.005	/h	0.129135	GJ	0.163718	GJ	0.034582	GJ	24.65625	12.5625
11-01-2023	14:10:45	198.252	/h	3.289418	m/s	9.310189	m3	10.24957	m3	0.939381	m3	10.557	/h	0.157596	GJ	0.192178	GJ	0.034582	GJ	24.78125	12.0625
11-01-2023	14:10:55	196.511	/h	3.293711	m/s	9.86119	m3	10.80057	m3	0.939381	m3	9.74	/h	0.186439	GJ	0.221022	GJ	0.034582	GJ	24.4375	12.71875
11-01-2023	14:11:05	196.3	/h	3.29622	m/s	10.41267	m3	11.35205	m3	0.939381	m3	10.015	/h	0.215308	GJ	0.249691	GJ	0.034582	GJ	24.5625	12.5
11-01-2023	14:11:15	197.822	/h	3.282284	m/s	10.90772	m3	11.8471	m3	0.939381	m3	10.482	/h	0.240849	GJ	0.275431	GJ	0.034582	GJ	25.03125	12.46875
11-01-2023	14:11:25	198.371	/h	3.291395	m/s	11.4579	m3	12.39728	m3	0.939381	m3	10.693	/h	0.269657	GJ	0.30424	GJ	0.034582	GJ	24.59375	11.71875
11-01-2023	14:11:35	198.322	/h	3.290582	m/s	12.00874	m3	12.94812	m3	0.939381	m3	11.002	/h	0.290991	GJ	0.333673	GJ	0.034582	GJ	24.9375	11.6875
11-01-2023	14:11:45	198.363	/h	3.291258	m/s	12.55997	m3	13.49936	m3	0.939381	m3	10.745	/h	0.328654	GJ	0.363236	GJ	0.034582	GJ	24.875	11.9375
11-01-2023	14:11:55	198.364	/h	3.291283	m/s	13.11072	m3	14.0501	m3	0.939381	m3	10.589	/h	0.357902	GJ	0.392485	GJ	0.034582	GJ	24.5625	11.8125
11-01-2023	14:12:05	198.736	/h	3.297457	m/s	13.66234	m3	14.60172	m3	0.939381	m3	10.349	/h	0.386844	GJ	0.421426	GJ	0.034582	GJ	24.46875	12.03125
11-01-2023	14:12:15	198.454	/h	3.292782	m/s	14.21416	m3	15.15354	m3	0.939381	m3	10.152	/h	0.415232	GJ	0.449814	GJ	0.034582	GJ	24.8125	12.59375
11-01-2023	14:12:25	197.94	/h	3.28425	m/s	14.765	m3	15.70438	m3	0.939381	m3	10.54	/h	0.444081	GJ	0.478664	GJ	0.034582	GJ	24.71875	12
11-01-2023	14:12:35	197.919	/h	3.283893	m/s	15.31499	m3	16.25437	m3	0.939381	m3	10.591	/h	0.473275	GJ	0.507858	GJ	0.034582	GJ	24.65625	11.875
11-01-2023	14:12:45	197.864	/h	3.282976	m/s	15.86483	m3	16.80421	m3	0.939381	m3	10.485	/h	0.50262	GJ	0.537202	GJ	0.034582	GJ	24.21875	11.5625
11-01-2023	14:12:55	197.559	/h	3.277928	m/s	16.35921	m3	17.29859	m3	0.939381	m3	10.572	/h	0.528615	GJ	0.563197	GJ	0.034582	GJ	24.78125	12.25
11-01-2023	14:13:05	197.42	/h	3.275614	m/s	16.9077	m3	17.84708	m3	0.939381	m3	10.461	/h	0.557973	GJ	0.592555	GJ	0.034582	GJ	24.71875	12.0625
11-01-2023	14:13:15	197.444	/h	3.276016	m/s	17.45601	m3	18.39539	m3	0.939381	m3	10.462	/h	0.587107	GJ	0.621689	GJ	0.034582	GJ	24.90625	12.25
11-01-2023	14:13:25	197.493	/h	3.276824	m/s	18.00446	m3	18.94384	m3	0.939381	m3	10.517	/h	0.615874	GJ	0.650456	GJ	0.034582	GJ	25.03125	12.3125
11-01-2023	14:13:35	197.344	/h	3.27436	m/s	18.55303	m3	19.49242	m3	0.939381	m3	10.638	/h	0.644936	GJ	0.679518	GJ	0.034582	GJ	24.53125	11.65625
11-01-2023	14:13:45	197.383	/h	3.274999	m/s	19.101	m3	20.04038	m3	0.939381	m3	10.562	/h	0.673929	GJ	0.708511	GJ	0.034582	GJ	24.375	11.59375
11-01-2023	14:13:55	197.792	/h	3.28179	m/s	19.64997	m3	20.58935	m3	0.939381	m3	10.967	/h	0.703025	GJ	0.737608	GJ	0.034582	GJ	24.15625	12
11-01-2023	14:14:05	197.807	/h	3.282043	m/s	20.19937	m3	21.13875	m3	0.939381	m3	10.973	/h	0.732066	GJ	0.766648	GJ	0.034582	GJ	24.875	11.625
11-01-2023	14:14:15	198.045	/h	3.285984	m/s	20.74932	m3	21.6887	m3	0.939381	m3	10.676	/h	0.760387	GJ	0.794969	GJ	0.034582	GJ	25.03125	12.15625
11-01-2023	14:14:25	197.692	/h	3.280135	m/s	21.29911	m3	22.23849	m3	0.939381	m3	10.32	/h	0.789426	GJ	0.824009	GJ	0.034582	GJ	24.5625	12.09375
11-01-2023	14:14:35	197.838	/h	3.282548	m/s	21.7936	m3	22.73298	m3	0.939381	m3	9.914	/h	0.815471	GJ	0.850053	GJ	0.034582	GJ	24.8125	11.65625
11-01-2023	14:14:45	197.875	/h	3.283174	m/s	22.34302	m3	23.2824	m3	0.939381	m3	11.029	/h	0.845058	GJ	0.87964	GJ	0.034582	GJ	24.8125	12.4375
11-01-2023	14:14:55	197.974	/h	3.284809	m/s	22.89297	m3	23.83236	m3	0.939381	m3	10.957	/h	0.874574	GJ	0.909156	GJ	0.034582	GJ	24.6875	11.46875
11-01-2023	14:15:05	198.076	/h	3.286503	m/s	23.44322	m3	24.3826	m3	0.939381	m3	10.366	/h	0.903393	GJ	0.937975	GJ	0.034582	GJ	24.625	12.125
11-01-2023	14:15:15	198.49	/h	3.293373	m/s	23.99495	m3	24.93343	m3	0.939381	m3	10.646	/h	0.932588	GJ	0.96717	GJ	0.034582	GJ	24.59375	11.78125
11-01-2023	14:15:25	198.131	/h	3.287418	m/s	24.5446	m3	25.48399	m3	0.939381	m3	10.81	/h	0.961768	GJ	0.996351	GJ	0.034582	GJ	24.875	11.84375
11-01-2023	14:15:35	197.983	/h	3.284966	m/s	25.09469	m3	26.03408	m3	0.939381	m3	10.646	/h	0.990543	GJ	1.025125	GJ	0.034582	GJ	24.75	11.90625
11-01-2023	14:15:45	197.866	/h	3.28302	m/s	25.64443	m3	26.58381	m3	0.939381	m3	10.951	/h	1.019788	GJ	1.05437	GJ	0.034582	GJ	25.09375	11.875
11-01-2023	14:15:55	197.94	/h	3.284246	m/s	26.19402	m3	27.1334	m3	0.939381	m3	10.23	/h	1.048774	GJ	1.083356	GJ	0.034582	GJ	24.78125	12.4375

TF1100 series ultrasonic flowmeter can storage: data, time, flow, velocity, net totalizer, positive totalizer, negative totalizer, EFR, E.T, Tin, Tout and T.D.



## APPENDIX 3 FLUID CHARACTERISTIC (SOUND SPEED)

### 1. FLUID PROPERTIES

Fluid	Specific Gravity	Sound Speed		delta-v/degree C	Kinematic Viscosity	Absolute viscosity
	20 degrees C	m/s	ft/s	m/s/degree C	Centistokes	Centipoise
Acetate, Butyl		1270	4163.9			
Acetate, Ethyl	0.901	1085	3559.7	4.4	0.489	0.441
Acetate, Methyl	0.934	1211	3973.1		0.407	0.380
Acetate, Propyl		1280	4196.7			
Acetone	0.79	1174	3851.7	4.5	0.399	0.316
Alcohol	0.79	1207	3960.0	4.0	1.396	1.101
Alcohol, Butyl	0.83	1270	4163.9	3.3	3.239	2.688
Alcohol, Ethyl	0.83	1180	3868.9	4	1.396	1.159
Alcohol, Methyl	0.791	1120	3672.1	2.92	0.695	0.550
Alcohol, Propyl		1170	3836.1			
Alcohol, Propyl	0.78	1222	4009.2		2.549	1.988
Ammonia	0.77	1729	5672.6	6.7	0.292	0.225
Aniline	1.02	1639	5377.3	4.0	3.630	3.710
Benzene	0.88	1306	4284.8	4.7	0.711	0.625
Benzol, Ethyl	0.867	1338	4389.8		0.797	0.691
Bromine	2.93	889	2916.7	3.0	0.323	0.946
n-Butane	0.60	1085	3559.7	5.8		
Butyrate, Ethyl		1170	3836.1			
Carbon dioxide	1.10	839	2752.6	7.7	0.137	0.151
Carbon tetrachloride	1.60	926	3038.1	2.5	0.607	0.968
Chloro-benzene	1.11	1273	4176.5	3.6	0.722	0.799
Chloroform	1.49	979	3211.9	3.4	0.550	0.819
Diethyl ether	0.71	985	3231.6	4.9	0.311	0.222
Diethyl Ketone		1310	4295.1			
Diethylene glycol	1.12	1586	5203.4	2.4		
Ethanol	0.79	1207	3960.0	4.0	1.390	1.097
Ethyl alcohol	0.79	1207	3960.0	4.0	1.396	1.101
Ether	0.71	985	3231.6	4.9	0.311	0.222
Ethyl ether	0.71	985	3231.6	4.9	0.311	0.222
Ethylene glycol	1.11	1658	5439.6	2.1	17.208	19.153
Freon R12		774.2	2540			
Gasoline	0.7	1250	4098.4			
Glycerin	1.26	1904	6246.7	2.2	757.100	953.946
Glycol	1.11	1658	5439.6	2.1		
Isobutanol	0.81	1212	3976.4			
Iso-Butane		1219.8	4002			
Isopentane	0.62	980	3215.2	4.8	0.340	0.211
Isopropanol	0.79	1170	3838.6		2.718	2.134
Isopropyl alcohol	0.79	1170	3838.6		2.718	2.134
Kerosene	0.81	1324	4343.8	3.6		

Linalool		1400	4590.2			
Linseed Oil	.925-.939	1770	5803.3			
Methanol	0.79	1076	3530.2	2.92	0.695	0.550
Methyl alcohol	0.79	1076	3530.2	2.92	0.695	0.550
Methylene chloride	1.33	1070	3510.5	3.94	0.310	0.411
Methylethyl Ketone		1210	3967.2			
Motor Oil (SAE 20/30)	.88-.935	1487	4875.4			
Octane	0.70	1172	3845.1	4.14	0.730	0.513

Oil, Castor	0.97	1477	4845.8	3.6	0.670	0.649
Oil, Diesel	0.80	1250	4101			
Oil (Lubricating X200)		1530	5019.9			
Oil (Olive)	0.91	1431	4694.9	2.75	100.000	91.200
Oil (Peanut)	0.94	1458	4783.5			
Paraffin Oil		1420	4655.7			
Pentane	0.626	1020	3346.5		0.363	0.227
Petroleum	0.876	1290	4229.5			
1-Propanol	0.78	1222	4009.2			
Refrigerant 11	1.49	828.3	2717.5	3.56		
Refrigerant 12	1.52	774.1	2539.7	4.24		
Refrigerant 14	1.75	875.24	2871.5	6.61		
Refrigerant 21	1.43	891	2923.2	3.97		
Refrigerant 22	1.49	893.9	2932.7	4.79		
Refrigerant 113	1.56	783.7	2571.2	3.44		
Refrigerant 114	1.46	665.3	2182.7	3.73		
Refrigerant 115		656.4	2153.5	4.42		
Refrigerant C318	1.62	574	1883.2	3.88		
Silicone (30 cp)	0.99	990	3248		30.000	29.790
Toluene	0.87	1328	4357	4.27	0.644	0.558
Transformer Oil		1390	4557.4			
Trichlorethylene		1050	3442.6			
1,1,1-Trichloro-e thane	1.33	985	3231.6		0.902	1.200
Turpentine	0.88	1255	4117.5		1.400	1.232
Water, distilled	0.996	1498	4914.7	-2.4	1.000	0.996
Water, heavy	1	1400	4593			
Water, sea	1.025	1531	5023	-2.4	1.000	1.025
Wood Alcohol	0.791	1076	3530.2	2.92	0.695	0.550
m-Xylene	0.868	1343	4406.2		0.749	0.650
o-Xylene	0.897	1331.5	4368.4	4.1	0.903	0.810
p-Xylene		1334	4376.8		0.662	

## 2. WATER SOUND SPEED

**Water Sound Speed table ( pressure: 1 bar)**

Units: Sound Speed: m/s

Temperature ℃	Sound Speed	Temperature ℃	Sound Speed	Temperature ℃	Sound Speed	Temperature ℃	Sound Speed
0	1402.3	25	1496.6	50	1542.5	75	1555.1
1	1407.3	26	1499.2	51	1543.5	76	1555.0
2	1412.2	27	1501.8	52	1544.6	77	1554.9
3	1416.9	28	1504.3	53	1545.5	78	1554.8
4	1421.6	29	1506.7	54	1546.4	79	1554.6
5	1426.1	30	1509.0	55	1547.3	80	1554.4
6	1430.5	31	1511.3	56	1548.1	81	1554.2
7	1434.8	32	1513.5	57	1548.9	82	1553.9
8	1439.1	33	1515.7	58	1549.6	83	1553.6
9	1443.2	34	1517.7	59	1550.3	84	1553.2
10	1447.2	35	1519.7	60	1550.9	85	1552.8
11	1451.1	36	1521.7	61	1551.5	86	1552.4
12	1454.9	37	1523.5	62	1552.0	87	1552.0
13	1458.7	38	1525.3	63	1552.5	88	1551.5
14	1462.3	39	1527.1	64	1553.0	89	1551.0
15	1465.8	40	1528.8	65	1553.4	90	1550.4
16	1469.3	41	1530.4	66	1553.7	91	1549.8
17	1472.7	42	1532.0	67	1554.0	92	1549.2
18	1476.0	43	1533.5	68	1554.3	93	1548.5
19	1479.1	44	1534.9	69	1554.5	94	1547.5
20	1482.3	45	1536.3	70	1554.7	95	1547.1
21	1485.3	46	1537.7	71	1554.9	96	1546.3
22	1488.2	47	1538.9	72	1555.0	97	1545.6
23	1491.1	48	1540.2	73	1555.0	98	1544.7
24	1493.9	49	1541.3	74	1555.1	99	1543.9

## 3. PIPE MATERIAL SOUND SPEED TABLE

Pipe Material Sound Speed Table	Sound Speed(m/s)	Liner Material	Sound Speed (m/s)
Steel	3206	Teflon	1225
ABS	2286	Titanium	3150
Aluminum	3048	Cement	4190
Brass	2270	Tar Epoxy	2540
Cast Iron	2460	Porcelain Enamel	2540
Bronze	2270	Glass	5970
Fiber Glass	3430	Plastic	2280
Glass	3276	Polyethylene	1600
Polyethylene	1950	PTFE	1450
PVC	2540	Rubber	1600



**Lanry Instruments (Shanghai) Co.,Ltd**

Add: 6 Floor, Block F,Bldg 5,No.2800 Jiuxin Rd., Songjiang District, Shanghai 201612,China

Tel: 86 21-67801665,67618991

Fax: 86 21-67801625

<http://www.lanry-flow.com>